

VENTLESS KITCHEN RANGE HOOD FOR 120 V. OPERATION



KITCHEN
RANGE HOOD
MODEL

RH7630XL

INSTALLATION INSTRUCTIONS

READ AND SAVE THESE INSTRUCTIONS

Before you begin, read the following instructions completely and carefully. If followed, they will simplify the installation job.

**IMPORTANT: OBSERVE ALL GOVERNING CODES
AND ORDINANCES**

**SAVE THESE INSTRUCTIONS FOR THE LOCAL
ELECTRICAL INSPECTOR'S USE**


For an easier installation, remove the filters and the three assemblies shown in Fig. 3. This reduces the weight about 40%. The blower cover and light frame assembly are held into place with thumb screws. To remove the blower assembly, first unplug the blower supply cord from the junction box. Remove the packing screw from the blower retaining rod, then pull the blower retaining rod to one side, freeing it from between the bumps on the blower housing.

1. Remove screw holding junction box cover.
2. Remove proper electrical knockout See Figure 1.
3. Lift the hood into position. Mark location of four mounting holes.
4. Remove hood and start all four screws in center of narrow neck of keyhole slot marked on cabinet bottom. (Fig. 2).
5. Lift into position on four screws simultaneously feeding electrical wire through knockout.
6. Complete electrical wiring in junction box according to the National Electrical Code and applicable Local codes.

NOTE: This unit must be permanently grounded.

7. Tighten screws to secure hood. Be sure screw head is in narrow neck of keyhole slot.
8. Replace junction box cover.
9. Replace blower cover, light frame assembly and filters.
10. Replace blower.




TOOLS AND MATERIALS REQUIRED



- Drill, electric or ratchet drive, with 1-1/4" wood bit (to drill an access hole in the cabinet or kitchen wall for the electric power line.)



- One common head screwdriver (to secure hood mounting screws to the cabinet and hood sheet metal parts).
- Pliers (for opening knockouts).
- Pencil, ruler and level for marking cabinet locations.
- Saber saw or keyhole saw for cutting the wall or cabinet openings.



OPERATION AND CARE OF UNIT

CARE OF FILTERS:

A. ALUMINUM FILTER: For greatest efficiency, the permanent type aluminum filter should be removed and cleaned periodically.

To clean, the filter should be soaked in hot water detergent, then thoroughly rinsed. The aluminum filter can be washed in a dishwasher.

B. CHARCOAL FILTER: This filter should be inspected periodically and when it becomes saturated should be replaced. There are no effective means of reactivating charcoal filters.

CARE OF EXTERIOR SURFACES:

Your range hood is a beautifully finished addition to your kitchen. To preserve its lasting beauty, clean with a mild detergent. **DO NOT** use abrasive cleaners.

LIGHTING

Select two light bulbs up to 75 watts each to achieve desired lighting level.

BLOWER CONTROL

This range hood has a solid state motor speed control. After setting the control to a desired speed, it will take approximately 15 seconds for the blower to respond to that setting.

For most effective removal of smoke and odors, turn on fan at beginning of cooking operation and allow to run until smoke and odors are removed from room.




FIG. 2





FIG. 1

FIG. 3

IMPORTANT SAFEGUARDS FOR ELECTRICAL APPLIANCES

When using electrical appliances, basic safety precautions should always be followed including the following:

1. Read and follow all instructions.
2. Close supervision is necessary when any appliance is used by or near children.
3. To avoid providing fuel for a grease pan fire, clean lint and grease from all hood surfaces—interior and exterior. Be sure to remove and clean air filter every three months.
4. Do not saturate electrical connections, switches, and motor in water during cleaning. Remember, **WATER AND ELECTRICITY DO NOT MIX!**
5. If any electrical malfunction becomes evident during use, disconnect power to hood at your home fuse or breaker box.



If you need service or assistance, we suggest you follow these four steps:

1. Before calling for assistance...

Performance problems often result from little things you can find and fix yourself without tools of any kind.

If nothing operates:

- Have you checked the main fuse or circuit breaker box?

2. If you need assistance...

Call the Whirlpool COOL-LINE® service assistance telephone number. Dial free from:

Continental U.S. (800) 253-1301
Michigan (800) 632-2243
Alaska & Hawaii (800) 253-1121

and talk with one of our trained Consultants. The Consultant can instruct you in how to obtain satisfactory operation from your appliance or, if service is necessary, recommend a qualified service company in your area.



3. If you need service...



Whirlpool has a nationwide network of franchised TECH-CARE® Service Companies. TECH-CARE service technicians are trained to fulfill the product warranty and provide after-warranty service anywhere in the United States. To locate TECH-CARE service in your area, call our COOL-LINE service assistance telephone number (see Step 2) or look in your telephone directory Yellow Pages under:

APPLIANCES—HOUSEHOLD MAJOR—SERVICES & REPAIR	OR	ELECTRICAL APPLIANCES— MAJOR—REPAIRING & PARTS
WHIRLPOOL APPLIANCES FRANCHISED TECH-CARE SERVICE		WHIRLPOOL APPLIANCES FRANCHISED TECH-CARE SERVICE
SERVICE COMPANIES		SERVICE COMPANIES
XZY SERVICE CO		XZY SERVICE CO
123 Maple		999-9999 OR 123 Main
		999-9999
		WASHING MACHINES, DRYERS & IRONERS—SERVICING
		WHIRLPOOL APPLIANCES FRANCHISED TECH-CARE SERVICE
		SERVICE COMPANIES
		XZY SERVICE CO
		123 Main
		999-9999

4. If you have a problem...

Call our COOL-LINE service assistance telephone number (see Step 2) and talk with one of our Consultants or, if you prefer, write to:

Mr. Guy Turner, Vice President
Whirlpool Corporation
Administrative Center
2000 US-33 North
Benton Harbor, MI 49022

If you must call or write, please provide model number, serial number, date of purchase, and a complete description of the problem. This information is needed in order to better respond to your request for assistance.